

SmartDesign MSS

Ethernet MAC Configuration

Actel Corporation, Mountain View, CA 94043

© 2010 Actel Corporation. All rights reserved.

Printed in the United States of America

Part Number: 5-02-00238-1

Release: June 2010

No part of this document may be copied or reproduced in any form or by any means without prior written consent of Actel.

Actel makes no warranties with respect to this documentation and disclaims any implied warranties of merchantability or fitness for a particular purpose. Information in this document is subject to change without notice. Actel assumes no responsibility for any errors that may appear in this document.

This document contains confidential proprietary information that is not to be disclosed to any unauthorized person without prior written consent of Actel Corporation.

Trademarks

Actel and the Actel logo are registered trademarks of Actel Corporation.

Adobe and Acrobat Reader are registered trademarks of Adobe Systems, Inc.

All other products or brand names mentioned are trademarks or registered trademarks of their respective holders.

Table of Contents

Configuration Options	5
Port Description	6
A Product Support	9
Actel Customer Technical Support Center	9
Actel Technical Support	9
Website	9
Contacting the Customer Technical Support Center	9

Configuration Options

The SmartFusion Microcontroller Subsystem (MSS) provides one Ethernet MAC hard peripheral.

The actual behavior of the Ethernet MAC must be defined at the application level using the SmartFusion MSS MAC Driver provided by Actel.

In this document, we describe how you can enable the MSS MAC instance and select whether the Ethernet MAC interface is connected to dedicated MSS I/Os or the FPGA fabric.

For more details about the MSS MAC hard peripheral, please refer to the [Actel SmartFusion Microcontroller Subsystem User's Guide](#).

Enabling/Disabling the MAC Instance - On the MSS canvas, you need to enable (default) or disable the MAC instance (Figure 1) based on whether it is being used into your current application. If disabled, the MAC instance is held in reset (lowest power state) after the Actel system boot code is executed.




Figure 1 · MSS MAC Configurator

Connectivity Options - The MSS Ethernet MAC interface has been split into two groups - RMII Phy Management Interface and RMII Data Interface - (see [“Port Description”](#) on page 6 for the detailed port assignments).

You can choose to connect each group separately to either MSS I/Os or to the FPGA fabric as shown in Figure 2.

When using the A2F200M3F device you cannot connect the RMII Phy Management Interface to the FPGA fabric. This restriction does not exist for the A2F500M3G device. In all cases, the Ethernet MAC connectivity is automatically configured by the Actel system boot code.

MSS I/Os allocated to the MAC instance are available to connect to the FPGA fabric if the MAC instance is disabled. Refer to the [MSS I/O Configuration document](#) for more details. The MAC group ports are automatically promoted to the top level of the MSS Configurator Canvas so that they are available at the next level of hierarchy.




Figure 2 · MSS MAC Configuration Options

Ethernet MAC Clock Selection - If you enable the MAC peripheral on the MSS configurator canvas the MAC clock is automatically selected (read-only) in the Clock configurator. If you use the MSS Clock Configurator you need to select one of the following MAC clock sources.

- The external 10/100 clock (MAC_CLK pin) on the SmartFusion device.
- A clock generated in the MSS Clock Conditioning Circuit (MSS_CCC).

Port Description

Table 1 · MSS I/O Connectivity Options

Port Name	Port Group	Direction	PAD?	Description
MDIO	RMII_PHY_MGMT_PADs	INOUT	Yes	RMII management data input and output. The state of the input signal can be checked by reading the CSR9.19 bit. The output signal is driven by the CSR9.18 bit.
MDC	RMII_PHY_MGMT_PADs	OUT	Yes	RMII management clock = 25 MHz. This signal is driven by the CSR9.16 bit.
RXER	RMII_DATA_PADs	IN	Yes	Receive error. If RX_ER is asserted during Ethernet MAC reception, the frame is received and status of the frame is updated with RX_ER.
CRSDV	RMII_DATA_PADs	IN	Yes	Carrier sense and receive data valid. This signal must be asserted by the PHY when either a receive or transmit medium is non-idle. The PHY device should assert MAC_CRSDV when valid data is provided on the RXD signal.
RXD[1:0]	RMII_DATA_PADs	IN	Yes	Receive data recovered and decoded by PHY. The RXD[0] signal is the least significant bit.
TXEN	RMII_DATA_PADs	OUT	Yes	Transmit enable. When asserted, indicates valid data for the PHY on the TXD port.
TXD[1:0]	RMII_DATA_PADs	OUT	Yes	Transmit data. The TXD[0] signal is the least significant bit.

Table 2 · FPGA Fabric Connectivity Options

Port Name	Port Group	Direction	PAD?	Description
F2M_MDI	RMII_PHY_MGMT_FAB	IN	No	RMII management data input. The state of the input signal can be checked by reading the CSR9.19 bit
M2F_MDIO	RMII_PHY_MGMT_FAB	OUT	No	RMII management data output. The output signal is driven by the CSR9.18 bit.
M2F_MDC	RMII_PHY_MGMT_FAB	OUT	No	RMII management clock = 25 MHz. This signal is driven by the CSR9.16 bit.
F2M_RXER	RMII_DATA_FAB	IN	No	Receive error. If RX_ER is asserted during Ethernet MAC reception, the frame is received and status of the frame is updated with RX_ER.
F2M_CRSDV	RMII_DATA_FAB	IN	No	Carrier sense and receive data valid. This signal must be asserted by the PHY when either a receive or transmit medium is non-idle. The PHY device should assert MAC_CRSDV when valid data is provided on the RXD signal.
M2F_MDEN	RMII_DATA_FAB	OUT	No	RMII management data output enable.
F2M_RXD[1:0]	RMII_DATA_FAB	IN	No	Receive data recovered and decoded by PHY. The RXD[0] signal is the least significant bit.
M2F_TXEN	RMII_DATA_FAB	OUT	No	Transmit enable. When asserted, indicates valid data for the PHY on the TXD port.
M2F_TXD[1:0]	RMII_DATA_FAB	OUT	No	Transmit data. The TXD[0] signal is the least significant bit.

Product Support

Actel backs its products with various support services including Customer Service, a Customer Technical Support Center, a web site, an FTP site, electronic mail, and worldwide sales offices. This appendix contains information about contacting Actel and using these support services.

Customer Service

Contact Customer Service for non-technical product support, such as product pricing, product upgrades, update information, order status, and authorization.

From Northeast and North Central U.S.A., call **650.318.4480**

From Southeast and Southwest U.S.A., call **650.318.4480**

From South Central U.S.A., call **650.318.4434**

From Northwest U.S.A., call **650.318.4434**

From Canada, call **650.318.4480**

From Europe, call **650.318.4252** or **+44 (0) 1276 401 500**

From Japan, call **650.318.4743**

From the rest of the world, call **650.318.4743**

Fax, from anywhere in the world **650.318.8044**

Actel Customer Technical Support Center

Actel staffs its Customer Technical Support Center with highly skilled engineers who can help answer your hardware, software, and design questions. The Customer Technical Support Center spends a great deal of time creating application notes and answers to FAQs. So, before you contact us, please visit our online resources. It is very likely we have already answered your questions.

Actel Technical Support

Visit the [Actel Customer Support website \(www.actel.com/support/search/default.aspx\)](http://www.actel.com/support/search/default.aspx) for more information and support. Many answers available on the searchable web resource include diagrams, illustrations, and links to other resources on the Actel web site.

Website

You can browse a variety of technical and non-technical information on Actel's [home page](http://www.actel.com), at www.actel.com.

Contacting the Customer Technical Support Center

Highly skilled engineers staff the Technical Support Center from 7:00 A.M. to 6:00 P.M., Pacific Time, Monday through Friday. Several ways of contacting the Center follow:

Email

You can communicate your technical questions to our email address and receive answers back by email, fax, or phone. Also, if you have design problems, you can email your design files to receive assistance. We constantly monitor the email account throughout the day. When sending your request to us, please be sure to include your full name, company name, and your contact information for efficient processing of your request.

The technical support email address is tech@actel.com.

Phone

Our Technical Support Center answers all calls. The center retrieves information, such as your name, company name, phone number and your question, and then issues a case number. The Center then forwards the information to a queue where the first available application engineer receives the data and returns your call. The phone hours are from 7:00 A.M. to 6:00 P.M., Pacific Time, Monday through Friday. The Technical Support numbers are:

650.318.4460

800.262.1060

Customers needing assistance outside the US time zones can either contact technical support via email (tech@actel.com) or contact a local sales office. [Sales office listings](#) can be found at www.actel.com/company/contact/default.aspx.



Actel is the leader in low-power and mixed-signal FPGAs and offers the most comprehensive portfolio of system and power management solutions. Power Matters. Learn more at www.actel.com.

Actel Corporation • 2061 Stierlin Court • Mountain View, CA 94043 • USA

Phone 650.318.4200 • Fax 650.318.4600 • Customer Service: 650.318.1010 • Customer Applications Center: 800.262.1060

Actel Europe Ltd. • River Court, Meadows Business Park • Station Approach, Blackwater • Camberley Surrey GU17 9AB • United Kingdom

Phone +44 (0) 1276 609 300 • Fax +44 (0) 1276 607 540

Actel Japan • EXOS Ebisu Building 4F • 1-24-14 Ebisu Shibuya-ku • Tokyo 150 • Japan

Phone +81.03.3445.7671 • Fax +81.03.3445.7668 • <http://jp.actel.com>

Actel Hong Kong • Room 2107, China Resources Building • 26 Harbour Road • Wanchai • Hong Kong

Phone +852 2185 6460 • Fax +852 2185 6488 • www.actel.com.cn